





FUNCTION. DESIGN. QUALITY.

PROFILE DISPLAY STAND Assembly Instructions

Assembled Dimensions: 4.10 ft. x 9.85 ft.
Blanke Part No. 701-900-01



Parts List

a) Legs for display stand	(2 pieces)
b) Support beams	(2 pieces)
c) Hardware (8 ea. screws, nuts, washers) and shelf rails	
d) Shelf	(1 piece)
e) Rubber inlay	(1 piece)
f) Front shelf panel	(1 piece)
g) Header	(1 piece)
h) Shelf hooks	(72 pieces)



FUNCTION. DESIGN. QUALITY.

Before Assembly

Before assembling, Blanke Corporation recommends sorting the display components in the following order to make your experience easier:

1. Legs for display stand
2. Support beams
3. Shelf
4. Rubber inlay
5. Front shelf panel
6. Header
7. Shelf rails
8. Shelf hooks

The assembly will take place in the same order.

Assembly Instructions

1. Legs for display stand

Stand the display legs up, making sure the screw holes are facing outward.



2. Support beams

Use included screws to attach the support beams to the display legs.

3. Shelf

Insert the shelf into the assembled stand.

4. Rubber inlay

Place the black rubber inlay into the shelf after it is attached to the rest of the display stand.

5. Front shelf panel

Insert the panel into the groove in the front of the shelf.



FUNCTION. DESIGN. QUALITY.

Assembly Instructions (Continued)

6. Header

Hook header into the top of the assembled display

7. Shelf rails

Hook shelf rails into the front of the stand.

8. Shelf hooks

Attach shelf hooks into the shelf rails, assuring hooks are aligned to properly hold trims.

NOTE: Assembled shelf will have 35 - 36 spaces for different trims to be displayed to your preference.

Illustrations may vary. Technical changes and color deviations may occur from display to display.

Additional Images

